

# Moisture Extreme

Milliken™

**ADHESIVE**

NO RH limit  
NO testing required

FOR USE WITH:  
**Severe Moisture Conditions**

## USAGE OVERVIEW

**Moisture Extreme adhesive  
+ standard Milliken cushion backing**

6-pack / 22 oz. cans  
Spray-on



### NEW CONSTRUCTION



ON-GRADE<sup>1</sup>  
AND  
ABOVE-GRADE



READY TO INSTALL:  
30 days after concrete has been poured<sup>2</sup>



NO MOISTURE  
TESTING  
REQUIRED



NO  
LIMIT



NO  
LIMIT

### RENOVATION



ON-GRADE<sup>1</sup>



NO MOISTURE  
TESTING  
REQUIRED



NO  
LIMIT



NO  
LIMIT

Moisture Extreme is a worry-free solution designed for use if there are concerns about high moisture, or should there be a desire to avoid moisture testing



ABOVE-GRADE



Moisture Extreme is rarely (almost never) required for above-grade renovation scenarios — we recommend Non-Reactive Standard, TractionBack®, or TractionBack® Plus

Milliken Moisture Extreme essentially *eliminates* the possibility of a moisture-related failure.

<sup>1</sup> For below-grade scenarios, on-grade recommendations generally apply. However, please contact the Milliken Technical Services team (1-800-528-8453, option 2) to discuss your specific site parameters.

<sup>2</sup> Milliken's recommended minimum wait time for installations on newly poured concrete is 30 days. However, certain conditions may allow for installation to begin sooner. Please contact the Milliken Technical Services team for more information (1-800-528-8453, option 2).

For more detailed information and specifications, please refer to the current versions of Milliken's installation instructions and warranties, available at [millikenfloors.com](http://millikenfloors.com).



## Moisture Extreme adhesive + standard Milliken cushion backing

### PRIMARY BENEFITS

#### No testing? No worries

Sometimes a site presents severe moisture concerns, because of location, or climate, or some other reason. And then sometimes there is a pile of things to do, and you've decided worrying about moisture in the subfloor is definitely *not* going to be one of them. Maybe you don't want to do any testing — you just want to install some carpet.

The solution? Moisture Extreme adhesive.

#### ZERO moisture claims over the last 20+ years

- Moisture Extreme adhesive with standard cushion backing has NO RH or pH limits
- There is NO requirement to moisture test for ANY install
- Because Milliken has the best moisture management technology in the industry, our modular products are warranted *for life* against adhesive breakdown due to moisture vapor emissions

#### New construction: Do you recognize these choices?

- 1) Delay installation to comply with recommended concrete curing times or moisture levels
- 2) Decide to chance an early installation, or
- 3) Pay extra for concrete admixtures or for third-party moisture-mitigation

**Not with Milliken. With NO testing required, Moisture Extreme adhesive can be installed as early as 30 days after a completed pour.<sup>1</sup>** There are NO RH or pH limits.

### CONSIDERATIONS FOR THE REAL-WORLD

#### Do I really need to use Moisture Extreme? Let's find out.

**First of all**, if you're simply looking to make things easy on yourself, with total peace-of-mind — or, if there's absolutely *no way* you are going to do any moisture testing — then you should use Moisture Extreme. Otherwise, here are few things to think about:

**Is your job above grade?** Use Non-Reactive Standard — it's the right choice. Or for an adhesive-free solution, use TractionBack®. No moisture testing is required above grade for either product, there are no pH limits, and everything is fully warranted.

**Do you know your RH level?** If you do, and it's 95% or below, use Non-Reactive Standard.

**Are there any signs of moisture issues? Have you had a prior failure on the slab due to moisture?** For a prior failure, play it safe. Use Moisture Extreme. With signs of moisture issues, specifics matter. For example: You pulled up the old carpet up and saw something, maybe condensation. This *may* have been caused by the old product, in which case a Milliken modular product (using Non-Reactive Standard) will very likely solve the problem. Talk to your rep to be sure.

<sup>1</sup> Milliken's recommended minimum wait time for installations on newly poured concrete is 30 days. However, certain conditions may allow for installation to begin sooner. Please contact the Milliken Technical Services team for more information (1-800-528-8453, option 2).